



## Bi fold Vent

### Operation & Maintenance Manual

#### Internal Vent



#### External Grill

#### Bi fold Vent




Figure1. Bi-fold Vent Vent Internal Lid

#### Operation:

- Open and close the vent by tilting the lid on the internal vent, it has two lids which operate independently to each other.
- The Lid can be tilted to direct the air in the desired direction as shown on *figure 1*.

#### Maintenance:

- Every 3 months gently brush the external grill and internal vent with a hand brush to remove any cobwebs and wipe down with soapy water using a damp cloth.
- Do not use abrasive cleaning products or abrasive cleaning materials.
- Where possible, gently open the internal vent and vacuum the cut-out rout clearing out any dust and debris for efficient performance.

